



MAYO 2010 INKJET TINTA SIN CABEZAL

IMPRESORAS	MODELO CARTUCHO REFERENCIA	DARX 1	DARX 6	DARX 12	DARX 18	CODIGO
CANON BJ 300	BJI-642	2,67	2,52	2,38	2,22	2501
CANON BJ 600 AZUL	BJI-201 C	2,01	1,89	1,79	1,67	2502
CANON BJ 600 NEGRO	BJI-201 BK	2,01	1,89	1,79	1,67	2503
CANON BJ 600 ROJO	BJI-201 M	2,01	1,89	1,79	1,67	2504
CANON BJ 600 YELLOW	BJI-201 Y	2,01	1,89	1,79	1,67	2505
CANON BJ 800 / 820 / 880 BJPC8081 IBM 4079 BJI-643	BJI-643 NEGRO	2,60	2,45	2,31	2,16	2506
CANON BJ 800 / 820 / 880 BJPC8081 IBM 4079 BJI-643	BJI-643 AZUL	2,60	2,45	2,31	2,16	2507
CANON BJ 800 / 820 / 880 BJPC8081 IBM 4079 BJI-643	BJI-643 ROJO	2,60	2,45	2,31	2,16	2508
CANON BJ 800 / 820 / 880 BJPC8081 IBM 4079 BJI-643	BJI-643	2,60	2,45	2,31	2,16	2509
CANON BJ 2000 / 2100 / 4000 / 4100 / 4200 / 4300 / 4400 / 4550 / 4650 / 5000 / 5100 / 5500	BCI-21/24 NEGRO	2,00	1,88	1,78	1,66	2510
CANON BJ 2000 / 2100 / 4000 / 4100 / 4200 / 4300 / 4400 / 4550 / 4650 / 5000 / 5100 / 5500	BCI-21/24 COLOR	2,02	1,91	1,80	1,68	2511
CANON BJ-70 BC-11 / BDI-11 / C	BCI-11 NEGRO	3,13	2,95	2,78	2,60	2512
CANON BJ-70 BC-11 / BDI-11 / C	BCI-11 COLOR	3,97	3,74	3,53	3,30	2513
CANON BJC 3000 / 4000 / 5000 / 6000D / 8500 / 6100 / 6200 / 6500 i550 / i560 / i850 / i865 /	BCI-3BK NEGRO	2,12	2,00	1,88	1,76	2514
CANON BJC 3000 / 4000 / 5000 / 6000D / 8500 / 6100 / 6200 / 6500 i550 / i560 / i850 / i865 /	BCI-3/5/6Y	2,06	1,94	1,83	1,71	2515
CANON BJC 3000 / 4000 / 5000 / 6000D / 8500 / 6100 / 6200 / 6500 i550 / i560 / i850 / i865 /	BCI-3/5/6M	2,06	1,94	1,83	1,71	2516
CANON BJC 3000 / 4000 / 5000 / 6000D / 8500 / 6100 / 6200 / 6500 i550 / i560 / i850 / i865 /	BCI-3/5/6C CYAN	2,06	1,94	1,83	1,71	2517
CANON BJC 3000 / 4000 / 5000 / 6000D / 8500 / 6100 / 6200 / 6500 i550 / i560 / i850 / i865 /	BCI-6 BCI-5	2,06	1,94	1,83	1,71	2518
CANON BJC 7000 / 7100 / 8000 / 7004 Photo 700 J	BCI-61 COLOR	6,10	5,75	5,42	5,07	2519
CANON BJC 7000 / 7100 / 8000 / 7004 Photo 700 J	BCI-62 PHOTO	6,67	6,29	5,94	5,55	2520
CANON BJC 8500	BCI-8 BK NEGRO	2,06	1,94	1,83	1,71	2521
CANON BJC 8500	BCI-8 CYAN	2,06	1,94	1,83	1,71	2522
CANON BJC 8500	BCI-8 MAGENTA	2,06	1,94	1,83	1,71	2523
CANON BJC 8500	BCI-8 YELLOW	2,06	1,94	1,83	1,71	2524
CANON PIXMA MX 700 / 850 IP 4200 / 4500 / 5200 / 5200R / 6600D MP500 / 600 / 800	PGI5BK NEGRO	2,89	2,72	2,57	2,40	2525
CANON PIXMA MX 700 IP 4200 / 4500 / 5200 / 5200R / 6600D MP500 / 600 / 800	CL18BK NEGRO	2,83	2,67	2,51	2,35	2526
CANON PIXMA MX 700 IP 4200 / 4500 / 5200 / 5200R / 6600D MP500 / 600 / 800	CL18Y YELLOW	2,83	2,67	2,51	2,35	2527
CANON PIXMA MX 700 IP 4200 / 4500 / 5200 / 5200R / 6600D MP500 / 600 / 800	CL18C CYAN	2,83	2,67	2,51	2,35	2528
CANON PIXMA MX 700 IP 4200 / 4500 / 5200 / 5200R / 6600D MP500 / 600 / 800	CL18M MAGENTA	2,83	2,67	2,51	2,35	2529
CANON PIXMA IP 3600 / 4600 MP 540	PGI520BK NEGRO	3,59	3,39	3,20	2,99	2530
CANON PIXMA IP 3600 / 4600 MP 620 / 630 / 980 / 540	CL1521K NEGRO	3,56	3,36	3,17	2,96	2531
CANON PIXMA IP 3600 / 4600 MP 620 / 630 / 980 / 540	CL1521Y YELLOW	3,56	3,36	3,17	2,96	2532
CANON PIXMA IP 3600 / 4600 MP 620 / 630 / 980 / 540	CL1521C CYAN	3,56	3,36	3,17	2,96	2533
CANON PIXMA IP 3600 / 4600 MP 620 / 630 / 980 / 540	CL1521M	3,56	3,36	3,17	2,96	2534
EPSON Stylus 870 / 1170	SO20010 NEGRO	3,71	3,50	3,31	3,09	2701
EPSON Stylus 400 / 800 / 800+ / 1000	SO20025 NEGRO	2,27	2,14	2,02	1,89	2702
EPSON Stylus 700V / 900C / 910C / 5000C / 5100C	SO20034 NEGRO	2,16	2,04	1,93	1,80	2703
EPSON Stylus 700V / 900C / 910C / 5000C / 5100C	SO20036 COLOR	2,71	2,55	2,41	2,25	2704
EPSON Stylus 200 / 820 / COLORII / COLORIIS	SO20047LB	2,15	2,03	1,92	1,79	2705
EPSON Stylus 820 / 1500 / COLORII / COLORIIS	SO20049LB	2,44	2,30	2,17	2,03	2706
EPSON Stylus 1500	SO20062 NEGRO	4,02	3,79	3,57	3,34	2707
EPSON Stylus Photo 700 / 750	SO20110 SO20193	2,33	2,20	2,08	1,94	2708
EPSON Stylus 3000 Pro-5000	SO20118 NEGRO	3,50	3,30	3,11	2,91	2709
EPSON Stylus 3000	SO20130 AZUL	3,50	3,30	3,11	2,91	2710
EPSON Stylus 3000	SO20126 ROJO	3,50	3,30	3,11	2,91	2711
EPSON Stylus 3000 Pro-5000	SO20122	3,50	3,30	3,11	2,91	2712
EPSON Stylus 300	SO20138 COLOR	2,55	2,40	2,27	2,12	2713
EPSON Stylus Pro 5000	SO20143	4,86	4,58	4,32	4,04	2714
EPSON Stylus Pro 5000	SO20147 CYAN	2,15	2,03	1,92	1,79	2715
EPSON Stylus Color 400 / 440 / 460 / 480 / 500 / 580 / 600 / 640 / 660 / 670 / C20 / C40 /	SO20093 SO20187	1,96	1,85	1,74	1,63	2716
EPSON Stylus Color 200 / 500	SO20097 COLOR	2,44	2,30	2,17	2,03	2717
EPSON Stylus Color 400 / 440 / 460 / 480 / 580 / 600 / 640 / 660 / 670 / 740 / 760 / 800 / 850	SO20089 SO20191	2,19	2,06	1,95	1,82	2718
EPSON Stylus Color 740 / 760 / 800 / 850 / 860 / 1160 / 1520 / 2000 / 2500	SO20108 SO20189	2,10	1,98	1,87	1,75	2719
EPSON Stylus Color 400 / 440 / 460 / 480 / 500 / 580 / 600 / 640 / 660 / 670 / C20 / C40 /	SO20187 SO20093	2,02	1,91	1,80	1,68	2720
EPSON Stylus Color 740 / 760 / 800 / 850 / 860 / 1160 / 1520 / 2000 / 2500	SO20189 SO20108	2,02	1,91	1,80	1,68	2721
EPSON Stylus Color 400 / 440 / 460 / 480 / 580 / 600 / 640 / 660 / 670 / 740 / 760 / 800 / 850	SO20191 SO20089	2,34	2,21	2,09	1,95	2722
EPSON Stylus Photo 1200	TO01011 COLOR	2,79	2,63	2,48	2,32	2723
EPSON Stylus Color 900 / 980	TO03011 NEGRO	2,36	2,22	2,10	1,96	2724
EPSON Stylus Color 900 / 980	TO05011 COLOR	2,58	2,44	2,30	2,15	2725
EPSON Stylus Photo 790 / 870 / 875DC / 890 / 895 / 915 900 / 1270 / 1290 / 1290S	TO07 NEGRO	2,14	2,02	1,90	1,78	2726
EPSON Stylus Photo 790 / 870 / 875DC / 890 / 895 / 915	TO08 COLOR	2,45	2,31	2,18	2,04	2727
EPSON Stylus Photo 900 / 1270 / 1290 / 1290S	TO09 COLOR	2,72	2,56	2,42	2,26	2728
EPSON Stylus Color 480 / 580 / C20 / C40 / C40+	TO13401 NEGRO	1,96	1,85	1,74	1,63	2729
EPSON Stylus Color 480 / 580 / C20 / C40 / C40+	TO14401 COLOR	2,34	2,21	2,09	1,95	2730
EPSON Stylus Photo 2000P	TO15 NEGRO	2,25	2,12	2,00	1,87	2731
EPSON Stylus Photo 2000P	TO16 COLOR	3,23	3,05	2,88	2,69	2732
EPSON Stylus Color 680 / 680T / 685	TO17401 NEGRO	2,19	2,06	1,95	1,82	2733
EPSON Stylus Color 680 / 680T / 685	TO18401 COLOR	2,45	2,31	2,18	2,04	2734

EPSON Stylus Color 880 / 880T	TO19401 NEGRO	2,02	1,91	1,80	1,68	2735
EPSON Stylus Color 880 / 880T	TO20401 COLOR	2,34	2,21	2,09	1,95	2736
EPSON Stylus Color Photo 810 / 830 / 830U / 925 / 935	TO26401 NEGRO	2,16	2,04	1,93	1,80	2737
EPSON Stylus Color Photo 810 / 830 / 830U / 925 / 935	TO27401 COLOR	2,45	2,31	2,18	2,04	2738
EPSON Stylus Color C60 / C61	TO28401 NEGRO	2,16	2,04	1,93	1,80	2739
EPSON Stylus Color C60 / C61	TO29401 COLOR	2,38	2,25	2,12	1,98	2740
EPSON Stylus C70 / C70+ / C80 / C82 / CX5200 / CX5400	TO321 NEGRO	2,31	2,18	2,05	1,92	2741
EPSON Stylus C70 / C70+ / C80	TO322 CYAN	2,27	2,14	2,02	1,89	2742
EPSON Stylus C70 / C70+ / C80	TO323 MAGENTA	2,27	2,14	2,02	1,89	2743
EPSON Stylus C70 / C70+ / C80	TO324 YELLOW	2,27	2,14	2,02	1,89	2744
EPSON Stylus C82 / CX5200 / CX5400	TO422 CYAN	2,19	2,06	1,95	1,82	2745
EPSON Stylus C82 / CX5200 / CX5400	TO423 MAGENTA	2,19	2,06	1,95	1,82	2746
EPSON Stylus C82 / CX5200 / CX5400	TO424 YELLOW	2,19	2,06	1,95	1,82	2747
EPSON Stylus Color C42 / C44PLUS / C46	TO36401 NEGRO	2,06	1,94	1,83	1,71	2748
EPSON Stylus Color C42 / C44PLUS / C46	TO37401 COLOR	2,26	2,13	2,01	1,88	2749
EPSON Stylus Color C48	TO66140 NEGRO	2,08	1,96	1,85	1,73	2750
EPSON Stylus Color C48	TO67040 COLOR	2,28	2,15	2,03	1,90	2751
EPSON Stylus Color C62 / CX3200	TO40401 NEGRO	2,18	2,05	1,94	1,81	2752
EPSON Stylus Color C62 / CX3200	TO41401 COLOR	2,38	2,25	2,12	1,98	2753
EPSON Stylus Color C84 / C84PE / C86 / CX6400 / CX6600	TO431 NEGRO	2,44	2,30	2,17	2,03	2754
EPSON C64 / C66 / C84 / C84PE / C86 / CX6600 / CX6400 / CX3600 / CX3650	TO441 NEGRO	2,09	1,97	1,86	1,74	2755
EPSON C64 / C66 / C84 / C84PE / C86 / CX6600 / CX6400 / CX3600 / CX3650	TO442 CYAN A.R.	2,09	1,97	1,86	1,74	2756
EPSON C64 / C66 / C84 / C84PE / C86 / CX6600 / CX6400 / CX3600 / CX3650	TO443 MAGENTA	2,09	1,97	1,86	1,74	2757
EPSON C64 / C66 / C84 / C84PE / C86 / CX6600 / CX6400 / CX3600 / CX3650	TO444 YELLOW	2,09	1,97	1,86	1,74	2758
EPSON C64 / C66 / C84 / C84PE / C86 / CX6600 / CX6400 / CX3600 / CX3650	TO452 CYAN	2,34	2,21	2,09	1,95	2759
EPSON C64 / C66 / C84 / C84PE / C86 / CX6600 / CX6400 / CX3600 / CX3650	TO453 MAGENTA	2,34	2,21	2,09	1,95	2760
EPSON C64 / C66 / C84 / C84PE / C86 / CX6600 / CX6400 / CX3600 / CX3650	TO454 YELLOW	2,34	2,21	2,09	1,95	2761
EPSON D68 / D68PE / D88 / DX3800 / DX3850 / DX4200 / DX4250 / DX4800 / DX4850	TO611 NEGRO	2,09	1,97	1,86	1,74	2762
EPSON D68 / D68PE / D88 / DX3800 / DX3850 / DX4200 / DX4250 / DX4800 / DX4850	TO612 CYAN	2,09	1,97	1,86	1,74	2763
EPSON D68 / D68PE / D88 / DX3800 / DX3850 / DX4200 / DX4250 / DX4800 / DX4850	TO613 MAGENTA	2,09	1,97	1,86	1,74	2764
EPSON D68 / D68PE / D88 / DX3800 / DX3850 / DX4200 / DX4250 / DX4800 / DX4850	TO614 YELLOW	2,09	1,97	1,86	1,74	2765
EPSON Photo 950	TO331 NEGRO	2,55	2,40	2,27	2,12	2766
EPSON Photo 950	TO332 CYAN	2,55	2,40	2,27	2,12	2767
EPSON Photo 950	TO333 MAGENTA	2,55	2,40	2,27	2,12	2768
EPSON Photo 950	TO334 YELLOW	2,55	2,40	2,27	2,12	2769
EPSON Photo 950	TO335 LIGHT	2,55	2,40	2,27	2,12	2770
EPSON Photo 950	TO336 LIGHT	2,55	2,40	2,27	2,12	2771
EPSON Photo 2100	TO341 NEGRO	2,55	2,40	2,27	2,12	2772
EPSON Photo 2100	TO342 CYAN	2,55	2,40	2,27	2,12	2773
EPSON Photo 2100	TO343 MAGENTA	2,55	2,40	2,27	2,12	2774
EPSON Photo 2100	TO344 YELLOW	2,55	2,40	2,27	2,12	2775
EPSON Photo 2100	TO345 LIGHT	2,55	2,40	2,27	2,12	2776
EPSON Photo 2100	TO346 LIGHT	2,55	2,40	2,27	2,12	2777
EPSON Photo 2100	TO347 LIGHT	2,55	2,40	2,27	2,12	2778
EPSON Photo 2100	TO348 MATTE	2,55	2,40	2,27	2,12	2779
EPSON Stylus Pro 7000	T460011 NEGRO	6,10	5,75	5,42	5,07	2780
EPSON Stylus Pro 7000	T461011	5,84	5,51	5,20	4,86	2781
EPSON Stylus Pro 7000	T462011 CYAN	5,84	5,51	5,20	4,86	2782
EPSON Stylus Pro 7000	T463011 YELLOW	5,84	5,51	5,20	4,86	2783
EPSON Stylus Pro 7000	T464011 LIGHT	5,84	5,51	5,20	4,86	2784
EPSON Stylus Pro 7000	T465011 LIGHT	5,84	5,51	5,20	4,86	2785
EPSON Photo R200 / R220 / R300 / R320 / RX500 / RX600 / RX620	TO481 NEGRO	2,09	1,97	1,86	1,74	2786
EPSON Photo R200 / R220 / R300 / R320 / RX500 / RX600 / RX620	TO482 CYAN	2,09	1,97	1,86	1,74	2787
EPSON Photo R200 / R220 / R300 / R320 / RX500 / RX600 / RX620	TO483 MAGENTA	2,09	1,97	1,86	1,74	2788
EPSON Photo R200 / R220 / R300 / R320 / RX500 / RX600 / RX620	TO484 YELLOW	2,09	1,97	1,86	1,74	2789
EPSON Photo R200 / R220 / R300 / R320 / RX500 / RX600 / RX620	TO485 LIGHT	2,09	1,97	1,86	1,74	2790
EPSON Photo R200 / R220 / R300 / R320 / RX500 / RX600 / RX620	TO486 LIGHT	2,09	1,97	1,86	1,74	2791
EPSON Stylus R800 / R1800	TO541 NEGRO	2,55	2,40	2,27	2,12	2792
EPSON Stylus R800 / R1800	TO542 CYAN	2,55	2,40	2,27	2,12	2793
EPSON Stylus R800 / R1800	TO543 MAGENTA	2,55	2,40	2,27	2,12	2794
EPSON Stylus R800 / R1800	TO544 YELLOW	2,55	2,40	2,27	2,12	2795
EPSON Stylus R800 / R1800	TO547 LIGHT	2,55	2,40	2,27	2,12	2796
EPSON Stylus R800 / R1800	TO548 NEGRO	2,55	2,40	2,27	2,12	2797
EPSON Stylus R800 / R1800	TO549 LIGHT	2,55	2,40	2,27	2,12	2798
EPSON Stylus Photo R240 / RX420 / RX425 / RX520	TO551 NEGRO	2,09	1,97	1,86	1,74	2799
EPSON Stylus Photo R240 / RX420 / RX425 / RX520	TO552 CYAN	2,09	1,97	1,86	1,74	2800
EPSON Stylus Photo R240 / RX420 / RX425 / RX520	TO553 MAGENTA	2,09	1,97	1,86	1,74	2801
EPSON Stylus Photo R240 / RX420 / RX425 / RX520	TO554 YELLOW	2,09	1,97	1,86	1,74	2802
EPSON Stylus Photo RX700	T5591 NEGRO	2,55	2,40	2,27	2,12	2803
EPSON Stylus Photo RX700	T5592 CYAN	2,55	2,40	2,27	2,12	2804
EPSON Stylus Photo RX700	T5593 MAGENTA	2,55	2,40	2,27	2,12	2805
EPSON Stylus Photo RX700	T5594 YELLOW	2,55	2,40	2,27	2,12	2806
EPSON Stylus Photo RX700	T5595 LIGHT	2,55	2,40	2,27	2,12	2807
EPSON Stylus Photo RX700	T5596 LIGHT	2,55	2,40	2,27	2,12	2808
EPSON Stylus Color Pro 9000	T 407011 NEGRO	9,39	8,86	8,36	7,81	2809
EPSON Stylus Color Pro 9000	T 410011C CYAN	9,39	8,86	8,36	7,81	2810
EPSON Stylus Color Pro 9000	T 412011 CYAN	9,39	8,86	8,36	7,81	2811
EPSON Stylus Color Pro 9000	T 411011	9,39	8,86	8,36	7,81	2812
EPSON Stylus Color Pro 9000	T 409011M	9,39	8,86	8,36	7,81	2813
EPSON Stylus Color Pro 9000	T 408011Y	9,39	8,86	8,36	7,81	2814
EPSON D 78 / 92 / 120 DX 4000 / 4050 / 4400 / 4450 / 5000 / 5050 / 6000 / 6050 / 7000	TO711 NEGRO	2,33	2,20	2,08	1,94	2815
EPSON D 78 / 92 / 120 DX 4000 / 4050 / 4400 / 4450 / 5000 / 5050 / 6000 / 6050 / 7000	TO712 CYAN	2,33	2,20	2,08	1,94	2816
EPSON D 78 / 92 / 120 DX 4000 / 4050 / 4400 / 4450 / 5000 / 5050 / 6000 / 6050 / 7000	TO713 MAGENTA	2,33	2,20	2,08	1,94	2817
EPSON D 78 / 92 / 120 DX 4000 / 4050 / 4400 / 4450 / 5000 / 5050 / 6000 / 6050 / 7000	TO714 YELLOW	2,33	2,20	2,08	1,94	2818
EPSON Stylus Photo R265 / R360 / R285 / RX560 / RX585	TO801 NEGRO	2,33	2,20	2,08	1,94	2819

EPSON Stylus Photo R265 / R360 / R285 / RX560 / RX585	W	TO802 CYAN	2,33	2,20	2,08	1,94	2820
EPSON Stylus Photo R265 / R360 / R285 / RX560 / RX585	W	TO803 MAGENTA	2,33	2,20	2,08	1,94	2821
EPSON Stylus Photo R265 / R360 / R285 / RX560 / RX585	W	TO804 YELLOW	2,33	2,20	2,08	1,94	2822
EPSON Stylus Photo R265 / R360 / R285 / RX560 / RX585	NE	TO805 CYAN	2,33	2,20	2,08	1,94	2823
EPSON Stylus Photo R265 / R360 / R285 / RX560 / RX585	NE	TO806 MAGENTA	2,33	2,20	2,08	1,94	2824
EPSON Stylus Photo R2400	W	TO591 NEGRO	2,85	2,69	2,54	2,37	2825
EPSON Stylus Photo R2400		TO592 CYAN	2,55	2,40	2,27	2,12	2826
EPSON Stylus Photo R2400		TO593 MAGENTA	2,55	2,40	2,27	2,12	2827
EPSON Stylus Photo R2400		TO594 YELLOW	2,55	2,40	2,27	2,12	2828
EPSON Stylus Photo R2400		TO595 CYAN	2,55	2,40	2,27	2,12	2829
EPSON Stylus Photo R2400		TO596 MAGE	2,55	2,40	2,27	2,12	2830
EPSON Stylus Photo R2400		TO597 GRIS	2,55	2,40	2,27	2,12	2831
EPSON Stylus Photo R2400		TO598 NEGRO	2,55	2,40	2,27	2,12	2832
EPSON Stylus Photo R2400		TO599 GRIS	2,55	2,40	2,27	2,12	2833
BROTHER MFC-580 ; MFC-590 ; MFC-890		BRLC 600BK	2,43	2,29	2,16	2,02	3201
BROTHER MFC-580 ; MFC-590 ; MFC-890		BRLC 600M	2,20	2,08	1,96	1,83	3202
BROTHER MFC-580 ; MFC-590 ; MFC-890		BRLC 600C CYAN	2,20	2,08	1,96	1,83	3203
BROTHER MFC-580 ; MFC-590 ; MFC-890		BRLC 600Y	2,20	2,08	1,96	1,83	3204
BROTHER MFX- 4820 C , DCP-4020C		BRLC 700BK	2,43	2,29	2,16	2,02	3205
BROTHER MFX- 4820 C , DCP-4020C		BRLC 700M	2,20	2,08	1,96	1,83	3206
BROTHER MFX- 4820 C , DCP-4020C		BRLC 700C CYAN	2,20	2,08	1,96	1,83	3207
BROTHER MFX- 4820 C , DCP-4020C		BRLC 700Y	2,20	2,08	1,96	1,83	3208
BROTHER MFC 3220C / 3220CN / 3320CN / 3420C / 3820CN , FAX-1815C / 1820C		BRLC 800BK	2,43	2,29	2,16	2,02	3209
BROTHER MFC 3220C / 3220CN / 3320CN / 3420C / 3820CN , FAX-1815C / 1820C		BRLC 800M	2,20	2,08	1,96	1,83	3210
BROTHER MFC 3220C / 3220CN / 3320CN / 3420C / 3820CN , FAX-1815C / 1820C		BRLC 800C CYAN	2,20	2,08	1,96	1,83	3211
BROTHER MFC 3220C / 3220CN / 3320CN / 3420C / 3820CN , FAX-1815C / 1820C		BRLC 800Y	2,20	2,08	1,96	1,83	3212
BROTHER MFC-210C / 215C / 410CN / 425CN / 620CN / 3240C / 3340CN / 5440CN / 5840CN /		BRLC	2,09	1,97	1,86	1,74	3213
BROTHER MFC-210C / 215C / 410CN / 425CN / 620CN / 3240C / 3340CN / 5440CN / 5840CN /		BRLC	2,04	1,93	1,82	1,70	3214
BROTHER MFC-210C / 215C / 410CN / 425CN / 620CN / 3240C / 3340CN / 5440CN / 5840CN /		BRLC 900C CYAN	2,04	1,93	1,82	1,70	3215
BROTHER MFC-210C / 215C / 410CN / 425CN / 620CN / 3240C / 3340CN / 5440CN / 5840CN /		BRLC 900Y	2,04	1,93	1,82	1,70	3216
BROTHER DCP 130C / 135C / 150C / 153C / 157C / 330C / 540CN / 240C / 750CW MFP 440CN		BRLC 970/1000BK	2,13	2,01	1,89	1,77	3217
BROTHER DCP 130C / 135C / 150C / 153C / 157C / 330C / 540CN / 240C / 750CW MFP 440CN		BRLC 970/1000M	2,10	1,98	1,87	1,75	3218
BROTHER DCP 130C / 135C / 150C / 153C / 157C / 330C / 540CN / 240C / 750CW MFP 440CN		BRLC 970/1000C	2,10	1,98	1,87	1,75	3219
BROTHER DCP 130C / 135C / 150C / 153C / 157C / 330C / 540CN / 240C / 750CW MFP 440CN		BRLC 970/1000Y	2,10	1,98	1,87	1,75	3220
BROTHER MFC 3360CN / MFC-5460CN / MFC-5860CN / MFC-3360C		BRLC 1000HYBK	0,00	0,00	0,00		3221
BROTHER DCP 145 / 165C / 385C / 585CW MFC- 6490CW	NE	BRLC 980/1100BK	2,28	2,15	2,03	1,90	3222
BROTHER DCP 145 / 165C / 385C / 585CW MFC- 6490CW	NE	BRLC 980/1100M	2,21	2,09	1,97	1,84	3223
BROTHER DCP 145 / 165C / 385C / 585CW MFC- 6490CW	NE	BRLC 980/1100C	2,21	2,09	1,97	1,84	3224
BROTHER DCP 145 / 165C / 385C / 585CW MFC- 6490CW	NE	BRLC 980/1100Y	2,21	2,09	1,97	1,84	3225
XEROX DOCUPRINT XJ4C XJ6C W-450	W	8R7660 NEGRO	2,32	2,19	2,07	1,93	3501
XEROX DOCUPRINT XJ4C XJ6C W-450 C-6 C-8		8R7661 CYAN	2,32	2,19	2,07	1,93	3502
XEROX DOCUPRINT XJ4C XJ6C W-450 C-6 C-8		8R7662	2,32	2,19	2,07	1,93	3503
XEROX DOCUPRINT XJ4C XJ6C W-450 C-6 C-8		8R7663 YELLOW	2,32	2,19	2,07	1,93	3504
XEROX DOCUPRINT C-6 C-8		8R7994 NEGRO	2,32	2,19	2,07	1,93	3505
XEROX DOCUPRINT M 750 / 760		8R12728 NEGRO	2,99	2,82	2,66	2,49	3506
XEROX DOCUPRINT M 750 / 760 / 940 / 950		8R7971 NEGRO	3,03	2,86	2,70	2,52	3507
XEROX DOCUPRINT M 750 / 760 / 940 / 950		8R7972 CYAN	2,32	2,19	2,07	1,93	3508
XEROX DOCUPRINT M 750 / 760 / 940 / 950		8R7973	2,32	2,19	2,07	1,93	3509
XEROX DOCUPRINT M 750 / 760 / 940 / 950		8R7974 YELLOW	2,32	2,19	2,07	1,93	3510